

Rear HUBCAP Index

Example: **HC-R203C-D**

A	=	
B	=	
C	=	CONE / Pointed
D	=	DOME / Std
E	=	
F	=	
G	=	
H	=	HUBO HOLE
I	=	
J	=	
_X	=	Extended Height Flange

Conversion Chart - Metric to Imperial

MM	=	Imperial Inches
102	=	4.000 Inches / 4" Inches
152	=	6.000 Inches / 6" Inches
165	=	6.500 Inches / 6-1/2" Inches
184	=	7.250 Inches / 7-1/4" Inches
197	=	7.750 Inches / 7-3/4" Inches
200	=	7.875 Inches / 7-7/8" Inches
203	=	8.000 Inches / 8" Inches
206	=	8.125 Inches / 8-1/8" Inches
210	=	8.250 Inches / 8-1/4" Inches
213	=	8.375 Inches / 8-3/8" Inches
216	=	8.500 Inches / 8-1/2" Inches
219	=	8.625 Inches / 8-5/8" Inches
235	=	9.250 Inches / 9-1/4" Inches
279	=	11.000 Inches / 11" Inches